

# Quick Start Guide

1

Plug the smaller (Mini-A) USB connector into the back of the H200 BIO. Depending on the power supplied by the host computer, you may require one or two USB connectors.



Plug the long USB connector into the host computer.

- If the yellow power LED flashes slowly on the drive, plug both the short power USB and long USB connector into the host computer.
- If the yellow power LED flashes quickly, power detection has timed out. Remove all USB connections and reconnect the cable.

2

If Autorun does not automatically start ACCESS Standard, double-click the Start.exe file from the root directory on the application partition.

3

On the main page of ACCESS Standard, click Personalize Device. Complete the instructions on the pages that follow to set the Administrator password (if applicable) and create a user. ***It is very important that you memorize the Administrator password or store it in a safe place.***



After you successfully complete the personalization process, you can access your private partition using a file manager.