

ALPHATALK TAA COMPLIANT PUSH-TO-TALK HEADSET WITH USB & QUICK DISCONNECT CABLE

Thank you for choosing the AlphaTalk Push-To-Talk (PTT) headset. Use the AlphaTalk Push-To-Talk headset on any PC via the USB connector on your computer.

This user guide contains the following sections:

1. Operating System
2. Features
3. Installation



1. Operating System


- Windows® 7, 8, 10, 11
- Mac® OS X 10.7 or higher
- Software: None required

2. Features

- USB cable
- Quick Disconnect (QD) cable for easy mobility
- In-line control board equipped PTT switch, RX volume and call ON/OFF switch
- Complete digital sound card
- Clear live voice transmission with VoIP
- Supports Teams, Skype, Avaya One-x agent, Cisco Jabber, Bria(X-Lite) and 3CX softphones with SoftLink

3. Installation

Connect the AlphaTalk Push-To-Talk QD headset into a USB-A or USB-C port on your computer. No installation is required, simply plug & play. Your AlphaTalk Push-To-Talk is fully functional once connected. (You might need to adjust your computer's input/output settings to select the AlphaTalk as the primary audio device).



For additional help

If you have additional questions, please visit datalocker.com
For warranty information, datalocker.com/warranty